





FORNEL



Adjustable High Chair

Technical Parameters

Material: FSC birch plywood
Warranty: 2 years
Dimensions: 19.7" x 17.7" x 35.4"
Max. load: 200 lb
Age: 3+ years to adult



Seat mounting:
Height - The seat is at the correct height when your child's elbows are level with the table top.
Depth - For correct depth of the seat, position the child's back against the backrest with the seat supporting 3/4 of the thighs. For the child's best comfort it is important that the seat depth is not too deep. Leave comfortable space between the front edge of the seat and back of the child's knee. The seat plate should not protrude more than 4-5 cm in front of the side legs. **Use plastic gliders included to increase stability.**

Footrest:
Height - The footrest is at the correct height when the sole of the child's foot can rest flat on the footrest, while the thighs are touching the seat.
Depth - Make sure the forward edge of the footrest NEVER protrudes beyond the front tip of the chair legs at floor level.

Maintenance:
Wipe with a clean damp cloth, wipe off excess of water with a dry cloth. Moisture may crack stain. We do not recommend the use of any detergent. Color may change if the chair is exposed to the sun.








Product information:
The chair is made of birch plywood (FSC-certified). It is certified to ASTM F404, the US high chair standard, and a Children's Product Certificate is available. Ages: 3+ years to adult for the chair alone; 6-36 months with the Fornel Baby Set (sold separately), once the baby can sit up unassisted.

WARNING
FALL HAZARD: Children have suffered severe head injuries including skull fractures when falling from high chairs. Falls can happen suddenly if child is not restrained properly.

- Always use restraints, and adjust to fit snugly.
- Stay near and watch child during use.
- It is recommended that the high chair be used only by children capable of sitting upright unassisted.
- The child should be secured in the high chair at all times by the restraint system.

Safety Warnings:
WARNING: Never leave child unattended. To make sure that child can move to and from the table independently and without the chair tipping over, the legs of the chair have special felt gliders. When the legs of the chair move upwards, the gliders help the chair to slide backwards and return to the right position. The gliders must be kept clean. The surface should be horizontal, smooth and somewhat hard. It is not recommended to put the chair on soft or high pile carpets or rugs in which the chair legs are immersed easily. Uneven floor can also be unsuitable for the chair.
The child should be secured in the high chair at all times by the restraining system. It is recommended that the high chair be used only by children capable of sitting upright unassisted. Do not use the chair unless all components are correctly fitted and adjusted. Pay special attention to the seat and foot plate: make sure these are properly fastened before you put your child on the chair.
The chair should always be placed on a stable horizontal surface with plastic gliders attached at all times. Be sure to retighten all screws 2 weeks after assembly of the chair. After that you should check and retighten the screws if necessary on a regular basis. Keep the Allen key for future use. Wood is a living material. Therefore, each sheet of plywood, from which the chair is made, is unique in its kind.

Warranty:
FORNEL chairs come with a 2-year warranty covering defects in materials and workmanship. Returns: 30 days. The present warranty shall not cover damages caused by normal use and wear, improper use of the product, as well as failure to comply with the assembly, use and maintenance instructions attached to the product. **For product registration for safety or recall, support and warranty claims** contact info@myfornel.com · (360) 499-2391 · myfornel.com. Melt Candle Company LLC, 1022 Diane Ave., Oak Harbor, WA 98277, USA.



Tightening: Tighten every bolt fully with the Allen key until the side panels clamp the seat and footrest firmly. Re-tighten all bolts 2 weeks after assembly, then check them regularly and every time you change a height.